


**PL-FM-3006-0904**

September 2004  
Issue 1

**Model MSC Series Parts Listing  
Integral Load Cell**

Note: Part Number Descriptions with an asterisk (\*) are not shown.

Ref. No.	Part No.	Description	MSC 100	MSC 200	MSC 500
1	SPK-MSC-133	Label Assembly, Top Housing	1	1	1
2	SPK-MSC-134	Top Housing Assembly	1	1	1
3	SPK-DF-110	Keypad	1	1	1
4	SPK-MSC-135	Printed Circuit Board Assembly	1	1	1
5	SPK-DF-0100	Loadcell Assembly, 100 lbf	1	-	-
	SPK-DF-0200	Loadcell Assembly, 200 lbf	-	1	-
	SPK-DF-0500	Loadcell Assembly, 500 lbf	-	-	1
6	SPK-DF-112	Battery Pack Assembly	1	1	1
7	SPK-DF-113	Bottom Housing Assembly	1	1	1
8	SPK-DF-114	Power Jack Cable Assembly	1	1	1
9	SPK-DF-115C	Loadcell Shaft	1	1	1
10	SPK-DF-117	Cable Assembly, 12 Pin	1	1	1
11	SPK-DF-US120V	Battery Charger, 120V US Mains	1	1	1
	SPK-DF-EU230V	Battery Charger, 230V EU Mains	1	1	1
	SPK-DF-UK230V	Battery Charger, 230V UK Mains	1	1	1
12	SPK-DF-HANDLE	Handle Assembly	1	1	1
13*	SPK-FMG-130	Carrying Case Assembly	1	1	1



Itin Scale Co., Inc.  
431 Avenue U  
Brooklyn, NY 11223  
PHONE: 718-336-5900  
FAX: 718-627-1313  
EMAIL:  
sales@itinscales.com  
www.itinscales.com